Quick Start of Blue gate ISDN Brave

Install BlueGate ISDN Brave Configuration software on your PC. Please, follow instructions in Installation.pdf.











Now it is time to save your setting into device.
Data Stausture
Bluegate ISDN Brave Data
After 40 seconds the Led of GSM starts fast blinking. Then if GSM is registered and full service, the Led is blinking slow. In another case see in Bluegate ISDN Brave Configuration in Diagnostics ->GSM Modules Status what is the matter.
🦺 untitled - Bluegate ISDN Brave Configuration 🛛 🔲 🗖 🔀
<u>File View Connection Options Service Help</u>
S Configuration Diagnostics
⊂ GSM1
Status: <mark>Idle</mark> Signal level: -81 dBm
- CCM2
Status: Idle Signal level: -65 dBm
Bluegate ISDN Brave
ISDN Lines
GSM Modules Status GSM Modules Credit
USB: COM6 - Connected
▼
Try to call